



(F) Fuel Pump



Connector Voltage

1. Disconnect the **2P** connector from the fuel pump.
2. Turn the main switch key to the “**ON**” position, and measure the voltage with a voltmeter between the connector terminals.
3. If the voltage differs from the battery voltage, the wiring harness or main switch is faulty.

Voltage	Between connector terminal	Approx. battery voltage
---------	----------------------------	-------------------------



W1016341

Fuel Pump Continuity

1. Disconnect the **2P** connector from the fuel pump.
2. Check the continuity between the connector terminals with an ohmmeter.
3. If it does not conduct, the fuel pump is faulty.

W1016134

(G) Engine Stop Solenoid



Connector Voltage

1. Disconnect the **3P** connector from the engine stop solenoid.
2. Turn the main switch key to the “**ON**” position, and measure the voltage with a voltmeter between the terminal **3** (Red / Black) and the terminal **2** (Black).
3. If the voltage differs from the battery voltage, the wiring harness or main switch is faulty.

Voltage	Terminal 3 - Terminal 2	Approx. battery voltage
---------	---------------------------------------	-------------------------

W1016508

Engine Stop Solenoid Test

1. Disconnect the **3P** connector from the engine stop solenoid.
2. Remove the engine stop solenoid from the engine.
3. Connect the jumper leads from the battery positive terminal to the terminal **1** (White), and from the battery negative terminal to the terminal **2** (Black).
4. If the solenoid plunger is not attracted, the engine stop solenoid is faulty.
5. Connect the jumper leads from the battery positive terminal to the terminal **3** (Red), and from the battery negative terminal to the terminal **2** (Black).
Push the solenoid plunger in by your finger, and then release it.
6. If the solenoid plunger is not held, the engine stop solenoid is faulty.

W1016653