



Separating Front Axle Assembly

1. Support the engine with a disassembly stand.
2. Remove the reinforcing plate.
3. Remove the front axle bracket mounting nuts, and separate the front axle assembly from the engine.

(When reassembling)

- Install the lock nuts, noting their locations.

Tightening torque	Front axle bracket mounting nut	M10 nut	60.8 to 70.6 N·m 6.2 to 7.2 kgf·m 44.8 to 52.1 ft·lbs
		M12 nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft·lbs
		M10 lock nut	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs

Séparation de l'ensemble du pont avant

1. Caler le moteur avec une béquille de démontage.
2. Retirer le plateau de réenforcement.
3. Retirer les écrous de montage du support de pont avant puis séparer l'ensemble du pont avant du moteur.

(Au remontage)

- Placer les contre-écrous en notant leurs emplacements.

Couple de serrage	Ecou de montage du support de Pont avant	Ecou M10	60,8 à 70,6 N·m 6,2 à 7,2 kgf·m
		Ecou M12	77,5 à 90,2 N·m 7,9 à 9,2 kgf·m
		Contre-ecrou M10	23,5 à 27,5 N·m 2,4 à 2,8 kgf·m