

INSTRUCTION MANUAL REARVIEW MIRROR KIT for KUBOTA TRACTOR MX5400 / MX6000 with CAB

■ Assembly Procedure

1. Apply heat resistant grease to collar (070) and spring (030).
2. Assemble spring (030), collar (070), plain washer (090), spring lock washer (110), bush (040) to stay (140) as bellow picture.
3. Insert plug (060) into mirror stay (010) and then insert spring pin (080) into hole of mirror stay (010).
4. Insert mirror stay (010) so that spring pin (080) fits into groove A of stay (140) and then fasten with nut (100).
5. Apply adhesive bond for rubber to plug (050) (060) and set to mirror stay (010).
6. Assemble mirror stay (010) into mirror (020) as shown in figure C.
7. Fasten stay (140) with bolt (120) from the rear side of the tractor as shown.
8. Stay (130) is assembled in the same way as 1 to 7.

IMPORTANT :

Make sure to assemble as follows.

- Collar (070) should be assembled with the holes shown in the figure facing up.
- Set the cracking direction of spring pin (080) on the lower side and make both spring pin (080)'s overhang even.
- Make sure plug (050) (060) fits into mirror stay (010).

◆ Tightening torque

Flange bolt (120): 23.5 to 27.5 N·m (2.4 to 2.8 kgf·m, 17.3 to 20.3 lbf·ft)

Nut (100): 31.4 to 34.4 N·m (3.2 to 3.5 kgf·m, 23.2 to 25.4 lbf·ft)

Screw of mirror (020): 3.0 to 3.5 N·m (0.31 to 0.36 kgf·m, 2.2 to 2.6 lbf·ft)

■ Parts list

