

Note:

Reference numbers 010, 070, 080, 070, 060, 050, 030, 090, and 100 removed and stored. If mower is used, they will need to be reinstalled. Lower link spacers were misplaced and had to be ordered. They need to be installed on the inside of lower link when the lifting arms are removed. The lifting arms take up the space occupied by the spacers, and the spacers are removed and stored.

