

RCK60-24B zerks

	Part#						zerks per
	K5651-31160	NIPPLE,GREASE	A00100 UNIVERSAL JOINT	60	100A0366	PTO Shaft	1
	K5651-31210	NIPPLE,GREASE	A00100 UNIVERSAL JOINT	90	100A0366	U-joints at both ends of PTO shaft	2
	K5763-44250	NIPPLE,GREASE(45')	A00700 PULLEY HOLDER	80	100A0366	Pulley housing above center blade	1
	K5763-44250	NIPPLE,GREASE(45')	A01001 BLADE	260	100A0366	top of outer blade pulleys	2
	K5763-12100	NIPPLE(GREASE,45')	A01300 TENSION PULLEY	130	100A0366	top of tensioner pulley	1
	K1122-15150	NIPPLE,GREASE	A01300 TENSION PULLEY	160	100A0366	Tensioner swing arm post	1
	K5763-74230	NIPPLE,GREASE	A10300 FRONT GAUGE WHEEL	16	100A0366	rim of gauge wheel	2
	K1122-15152	NIPPLE(GREASE,M6*1.0)	A10300 FRONT GAUGE WHEEL	90	100A0366	caster top of gauge wheel	2
	K5763-74230	NIPPLE,GREASE	A10602 REAR WHEEL	66	100A0366	rear wheels rims	2
	K5763-44250	NIPPLE,GREASE(45')	A20300 LIFT LINKAGE	110	100A0366	linckage above rear wheels	2
						total zerks	16

LA272 Zerks

	75599-81520	FITTING,GREASE(1/4-2	A01001 BOOM	60	100A0222	back ends of arms/front ends of arms	4
	75532-63470	FITTING GREASE(90DEG	B02501 CYLINDER (BOOM)[COMPONENT PARTS]	80	100A0222	end of back lift cylindar	2
	75599-81531	FITTING,GREASE(1/8-2	B02501 CYLINDER (BOOM)[COMPONENT PARTS]	90	100A0222	end of back lift cylindar	2
	75599-81531	FITTING,GREASE(1/8-2	B03001 CYLINDER (BUCKET)[COMPONENT PARTS]	80	100A0222	both ends of bucket cylindar	4
						total zerks	12

B7500HSD Zerks

	06613-10675	NIPPLE,GREASE	F10800 SPEED CONTROL PEDAL	65	100K0848	end of speed control pedal pivot shaft	1
	06613-10675	NIPPLE,GREASE	K10100 3-POINT LINKAGE 2(LIFT ROD)	60	100K0848	right 3ph lift rod	1
	06613-10675	NIPPLE,GREASE	K12000 3-POINT LINKAGE 1(TOP LINK)	80	100K0848	3ph top link	1
							3