



MAINTENANCE INTERVALS

B Series

Items
Engine oil
Engine oil filter
T/M fluid
T/M oil filter (HST)
T/M strainer (B10 Series/7800/3200)
Hydraulic oil filter (B20 Series/7800/3200)
Front axle case oil

B & L Series Tractors

B7410- B7510- B7610- B7800- B2630- B3030- B21

	50	100	200	300	400	500	600	Interval
	X	X	X	X	X	X	X	every 100hrs
	X		X		X		X	every 200hrs
	X			X			X	every 300hrs
	X			X			X	every 300hrs
				X			X	every 300hrs
	X			X			X	every 300hrs
				x			x	every 300hrs

B2320 - B2620 - B2920 - B3200 - B26

NEW								
	50	100	200	300	400	500	600	Interval
	X		X		X		X	every 200hrs
	X		X		X		X	every 200hrs
					X			every 400hrs
	X		X		X		X	every 200hrs
					X			every 400hrs
					X			every 400hrs
					X			every 400hrs

L Series - Manual Transmission

Items
Engine oil
Engine oil filter
T/M fluid
Hydraulic oil filter
Front axle case oil

L2800 - L3400 - L4400 - L39 - GrandL 30 Series

	50	100	200	300	400	500	600	Interval
	X	X	X	X	X	X	X	every 100hrs
	X		X		X		X	every 200hrs
	X				X			every 400hrs
	X		X		X		X	every 200hrs
	X				X			every 400hrs

GrandL 40 Series

NEW								
	50	100	200	300	400	500	600	Interval
	X		X		X		X	every 200hrs
	X		X		X		X	every 200hrs
					X			every 400hrs
					X			every 400hrs
					X			every 400hrs

L Series - HST Transmission

Items
Engine oil
Engine oil filter
T/M fluid
T/M oil filter (HST)
Hydraulic oil filter
Front axle case oil

L2800 - L3400 - L4400 - L48 - GrandL 30 Series

	50	100	200	300	400	500	600	Interval
	X	X	X	X	X	X	X	every 100hrs
	X		X		X		X	every 200hrs
	X				X			every 400hrs
	X		X		X		X	every 200hrs
	X		X		X		X	every 200hrs
	X				X			every 400hrs

GrandL 40 Series - L45

NEW								
	50	100	200	300	400	500	600	Interval
	X		X		X		X	every 200hrs
	X		X		X		X	every 200hrs
					X			every 400hrs
	X		X		X		X	every 200hrs
	X				X			every 400hrs
					X			every 400hrs