



Adjusting Shuttle Valve Neutral Position and Lever Guide Neutral Position (Continued)

7. Shift the free play "D" toward the forward direction and slowly lower the shuttle lever as shown in the figure. And visually inspect the clearance "X".
8. Shift the free play "D" toward the rear direction and slowly lower the shuttle lever (1) as shown in the figure. And visually inspect the clearance "Y".
9. Make sure the two clearance "X" and "Y" are just the same, with shuttle cable retaining nut (5).

NOTE

- The figure [C] is an example when the length of the shuttle cable (4) is misadjusted.

- (1) Shuttle Lever
- (2) Steering Post Cover
- (3) Shuttle Lever Guide
- (4) Shuttle Cable
- (5) Retaining Nut

[A] When the shuttle lever shift to forward.

[B] When the shuttle lever shift to reverse.

[C] The cable is misadjusted

[D] ROPS Model

[E] CABIN Model

W1113888