



MAINTENANCE INTERVALS

MX & M Series Tractors

M TLB

Does not apply

M59

NEW

Items
Engine oil
Engine oil filter
T/M fluid
T/M oil filter (HST)
Hydraulic oil filter
Front axle case oil

	50	100	200	300	400	500	600	Interval

	50	100	200	300	400	500	600	Interval
	X		X		X		X	every 200hrs
	X		X		X		X	every 200hrs
					X			every 400hrs
	X		X		X		X	every 200hrs
	X				X			every 400hrs
					X			every 400hrs

MX Series

MX5000

MX5100

NEW

Items
Engine oil
Engine oil filter
T/M fluid
Hydraulic oil filter
Front axle case oil

	50	100	200	300	400	500	600	Interval
	X	X	X	X	X	X	X	every 100hrs
	X		X		X		X	every 200hrs
	X				X			every 400hrs
	X		X		X		X	every 200hrs
	X				X			every 400hrs

	50	100	200	300	400	500	600	Interval
	X		X		X		X	every 200hrs
	X		X		X		X	every 200hrs
					X			every 400hrs
					X			every 400hrs
					X			every 400hrs

M40 Series

M5040 - M6040 - M7040 - M8540 - M9540

Does not apply

Items
Engine oil
Engine oil filter
T/M fluid
Hydraulic oil filter
Front axle gear case oil
Front differential case oil

	50	100	200	300	400	500	600	Interval
	X			X			X	every 300hrs
	X						X	every 600hrs
	X						X	every 600hrs
	X			X			X	every 300hrs
	X						X	every 600hrs
	X						X	every 600hrs

	50	100	200	300	400	500	600	Interval

Large M Series

M96X - M108S - M95X - M108X - M125X

M100X - M110X - M126X - M135X

NEW

Items
Engine oil
Engine oil filter
T/M fluid
Hydraulic oil filter
Front axle gear case oil
Front differential case oil

	50	100	200	300	400	500	600	Interval
	X			X			X	every 300hrs
	X						X	every 600hrs
	X						X	every 600hrs
	X		X		X		X	every 200hrs
	X						X	every 600hrs
	X						X	every 600hrs

	50	100	200	300	400	500	600	Interval
	X				X			every 400hrs
	X				X			every 400hrs
	X						X	every 600hrs
	X			X			X	every 300hrs
							X	every 600hrs
							X	every 600hrs