MAINTENANCE INTERVALS

Turf Products

T Series

T1570 - T1670 - T1770 - T1870

Items	50	100	200	300	400	500	600	Interval
Engine oil	X	X	X	X	X	X	X	every 100hrs
Engine oil filter	X		X		X		X	every 200hrs

T1880 - T2080 - T2380

NEW

Items	50	100	200	300	400	500	600	Interval
Engine oil		X	X	X	X	X	X	every 100hrs
Engine oil filter		X	X	X	X	X	X	or annually

ZG Series

ZG20 - ZG23

Items	50	100	200	300	400	500	600	Interval
Engine oil	X	X	X	X	X	X	X	every 100hrs
Engine oil filter	X		X		X		X	every 200hrs
T/M fluid			X		X		X	every 200hrs
T/M oil filter (HST)	X		X		X		X	every 200hrs
T/M strainer (ZG222/227) / Hydraulic oil filter (ZG327)			X		X		X	every 200hrs

ZG222 - ZG227 - ZG327

NEW

Items	50	150	200	250	350	400	450	Interval
Engine oil	X	X		X	X		X	every 100hrs
Engine oil filter	X			X			X	every 200hrs
T/M fluid						X		every 400hrs
T/M oil filter (HST)	X		X			X		every 200hrs
T/M strainer (ZG222/227) / Hydraulic oil filter (ZG327)						X		every 400hrs

ZD Series

ZD18 - ZD21 - ZD25 - ZD28

Items	50	100	200	300	400	500	600	Interval
Engine oil	X	X	X	X	X	X	X	every 100hrs
Engine oil filter	X		X		X		X	every 200hrs
T/M fluid			X		X		X	every 200hrs
T/M oil filter (HST)	X		X		X		X	every 200hrs
Hydraulic oil filter			X		X		X	every 200hrs

ZD321 - ZD326 - ZD331

NEW

Items	50	150	200	250	350	400	450	Interval
Engine oil	X		X		X		X	every 200hrs
Engine oil filter	X		X		X		X	every 200hrs
T/M fluid					X			every 400hrs
T/M oil filter (HST)	X		X		X		X	every 200hrs
Hydraulic oil filter					X			every 400hrs

GR Series

GR2100 - GR2100 - GR2010 - GR2110

Items	50	100	200	300	400	500	600	Interval
Engine oil	X	X	X	X	X	X	X	every 100hrs
Engine oil filter	X		X		X		X	every 200hrs
T/M fluid			X		X		X	every 200hrs
T/M oil filter (HST)	X		X		X		X	every 200hrs
Transmission strainer			X		X		X	every 200hrs
Front axle case oil			X		X		X	every 200hrs

Doesn not apply

Items								
Engine oil								
Engine oil filter								
T/M fluid								
T/M oil filter (HST)								
Transmission strainer								
Front axle case oil								

BX Series

BX1850 - BX2350 - BX24

Items	50	100	200	300	400	500	600	Interval
Engine oil	X	X	X	X	X	X	X	every 100hrs
Engine oil filter	X		X		X		X	every 200hrs
T/M fluid	X			X			X	every 300hrs
T/M oil filter (HST)	X			X			X	every 300hrs
T/M strainer				X			X	every 300hrs
Hydraulic oil filter	X			X			X	every 300hrs
Front axle case oil				×			×	every 300hrs

BX1860 - BX2360 - BX2660 - BX25

NEW

Items	50	100	200	300	400	500	600	Interval
Engine oil	X		X		X		X	every 200hrs
Engine oil filter	X		X		X		X	every 200hrs
T/M fluid					X			every 400hrs
T/M oil filter (HST)	X		X		X		X	every 200hrs
T/M strainer					X			every 400hrs
Hydraulic oil filter					X			every 400hrs
Front axle case oil					X			every 400hrs